

Basic Setup Steps:

- (1) Connect unit to power and network only.
- (2) Set up a computer on the same network to configure WebRelay-Quad TM . To do this, set the IP address of the computer to 192.168.1.50 with a netmask of 255.255.255.0.
- (3) Configure WebRelay-Quad™ using web browser. Do this by pointing browser to http://192.168.1.2/setup.html.

Password is webrelay (all lower case).

(4) Set the permanent IP address in the configuration page. Restart WebRelay-Quad ™ (remove power, re-apply power).

After restarting the unit, set your computer back to it's original settings and access WebRelay™ at its new IP address.

(5) Connect relay contacts.

Factory Default Settings

IP Address: 192.168.1.2 Subnet Mask: 255.255.255.0

Control Web Address: http://192.168.1.2


Setup Web Address: http://192.168.1.2/setup.html

Username: no username required Control Password: no password set

Setup Password: webrelay (all lower case)

Quick Start Guide





DC Power Supply Input (+)
DC Power Supply Input (-)

Relay 1 Common

Relay 1 Normally Closed Relay 1 Normally Open

Relay 2 Common

Relay 2 Normally Closed Relay 2 Normally Open

Relay 3 Common

Relay 3 Normally Closed Relay 3 Normally Open

Relay 4 Common

Relay 4 Normally Closed Relay 4 Normally Open

Note: WebRelay-Quad™ can be configured to operate at 10Mbps or 100Mbps. For best power savings and long term performance the 10Mbps setting is recommended

Full Users Manual may be downloaded from http://www.ControlByWeb.com

For technical support, email quesitons to support@ControlByWeb.com



a division of...

Xytronix Research & Design, Inc.

North Logan, Utah, USA